



**How to read this chart:**

1. Identify the model number light fixture you have. Model numbers can be found on the product packaging and within the serial number of your unit. The serial number is located on the back of the light fixture with the model number being identified as f
2. Locate the replacement item required by its description in the second column. The Replacement Part Number for this item can be found next to it in the "Replacement Part #" column.
3. The columns on the right indicate how many of the specific part(s) is used in your model. Please be sure to only order the quantity you require.

**How to obtain parts for products not under warranty:**

If your product is no longer under warranty and you require a replacement part, we recommend first contacting your local retailer. Many local retailers stock our replacement parts or can obtain one for you quickly. In addition, replacement parts can be

**How to obtain parts for products under warranty:**

Current-USA products carry a one year limited warranty from the date of purchase, lamps carry a 3-month limited warranty. If your product is within warranty and you require a replacement part, they can be obtained by either:

1. Contacting your local retailer and requesting a replacement part under warranty. Many dealers are able to get common replacement parts quickly for warranty service.
2. If your retailer is unable to help you, please fill out the information below and include a copy of your original purchase receipt to **1-760-727-7066**.

Name:

Mailing Address:

Phone Number:

Email Address:

Serial Number of Fixture:

Replacement Part Number Required:

Original retailer item was purchased from:

\*\* Please remember to include a copy of your original purchase receipt.

Upon receiving the above complete information, a warranty replacement part will be sent to you. Please allow 7-10 days for delivery.

<b>Replacement Part #</b>	<b>Description: Chiller Mini Tower Drop in</b>	<b>Fixture Model #2635</b>	<b>Fixture Model #2680</b>	<b>Fixture Model #2645</b>	<b>Fixture Model #2646</b>
<b>2843</b>	Inlet/Outlet Compression Fitting for Model #s 2645, 2646 (Version 1)			2	2
<b>2874</b>	Inlet/Outlet Compression Fittings; Model 2680 (Version 1)	2		2	
<b>2873</b>	Inlet/Outlet Compression Fittings; Models 2646 (Version 2)				2
<b>2875</b>	Inlet/Outlet Compression Fittings; Model 2635 (Version 1 & 2)	2			
<b>2844</b>	Temperature Probe; Models 2645, 2646 (Version 1) White Connector			1	1
<b>2889</b>	Temperature Probe; Models 2645, 2646 (Version 1) Black Connector			1	1
<b>2841</b>	Temperature Probe; Models 2645 (Version 2)			1	
<b>2885</b>	Temperature Probe; Model # 2645 (Version 3), 2646 (Version 2)			1	1
<b>2876</b>	Temperature Probe; Model 2680		1		
<b>2877</b>	Temperature Probe; Model 2635 (Version 1)	1			
<b>2863</b>	Temperature Probe; Model 2635 (Version2)	1			
<b>2596</b>	Fan Motor, Blade & Mount; Model 2635	1			
<b>2890</b>	Fuse; Model 2635 (version 1 & 2)	1			
<b>2891</b>	Fuse; Model 2645 (version 2 & 3)			1	
<b>2892</b>	Fuse; Model 2646 (version 2)				1